

Assembly Instructions

8501-B/Bnw E/Enw – 8512-B/Bnw E/Enw

Example shows 8504-E

Step 1

Open the lid. Screw up the frame.
Unscrew gear tray with Schuko sockets and etc.

Step 2

Insert the box in the cutout of the hollow bottom. Insert
support screws into the corresponding threaded holes.

Step 3

Screw leveling screws up to the stop.
Connect and insert equipment carrier.

